

Instruction Manual for Spatter Cap

Tubing

CP/CPF

1 Attachment of CP (CPF)

Insert Tubing into CP (CPF) in such a direction that the larger diameter side faces the tubing end.



⚠ Caution: CP (CPF) can be used only for PushOne series (except mini type).

2 Insert into tube fitting

Insert the tubing into a fitting following the instruction manual of the PushOne series.



3 Setting CP (CPF)

Push CP (CPF) to cover the fitting body.



4 Completing work

Check if CP (CPF) is properly attached.



CPP

1 Insert into tube fitting

Insert the tubing into a fitting following the instruction manual of the PushOne series, and check if the tubing is properly inserted.



2 Attaching CPP

Open CPP halved in advance and cover the tubing connection part with them.



(Note)

👉 If you use CPP for FS tubing, there will be a 1mm space between the outer surface of the FS tubing and the inner surface of CPP.

⚠ Caution: CPP can be used only for PushOne series (except mini type).

3 Fixing CPP

Fix the hook of the CPP and close the opened body.



4 Completing work

Check if CPP is properly attached.



Clean tubing

Processed tubing

PushOne fitting

QuickSeal fitting

Clean fitting/Chemifit

Bamboo-shoot fitting

Control switch/Detachable series

Jig/Tool/Accessory

Technical information

Reference